
Brecknell **GP100 / GP250 USB**

Portable Bench Scale



GP Series USB Portable Bench Scales features a USB virtual COM port that can easily provide communication between the scale and computer. Comes standard with NCI protocol and interfaces to most common shipping software packages including UPS™ Worldship Online.

Housed in a robust base constructed from 22 gauge steel with ribbed base is designed to protect against unwanted damage. Built-in carrying handles and a large easy-to-read 1" / 25 mm H digits, backlit LCD display. Four easy to use keys: On/Zero/Off, tare (100% range), Units lb/kg and hold that is ideal when weighing larger boxes that cover the display window. The scale operates on one 9V battery (included), AC adapter (not included) and a USB cable (not included). Scale will automatically turn off after two minutes if not used to help prolong battery life.





Capacity

100 lb x 0.2 lb / 45 kg x 0.1 kg 250 lb x 0.5 lb / 110 kg x 0.2 kg



One 9V battery (included), AC adapter and USB cable (not included)



Display

Four large 1" / 25 mm H digits with backlit LCD



Construction

22 gauge steel with ribbed base designed to protect against damage to the scale



OOOOO Operator Keys

Zero, Tare, Unit



GP100 / GP250 USB Portable Bench Scale

Specifications

Accuracy: ± 3 displayed divisions

Capacity:

100 x 0.2 lb / 45 x 0.1 kg 250 x 0.5 lb / 110 x 0.2 kg

Display: Four large 1" / 25 mm H digits, backlit LCD

digits for easy visibility

Power: Internal Battery: One 9 volt (included) AC Adapter: 9 VDC @ 200 mA (not included)

USB cable (not included)

Communication: USB interface cable

Construction: 22 gauge steel with ribbed base designed to protect against damage to the scale

Portable: Attached handle allows for easy transport

Discrete Switch Keyboard Technology: Unique key button design to ensure reliability and longevity. Attached handle allows for easy transport.

Electro-Mechanical Design: Ensures greater accuracy even at higher weight capacities

Keyboard Functions:

Hold Freezes weight on the display

only when a weight of 3 lbs or more is

placed on the scale

TARE Removes weight of empty container or

item placed on the scale to obtain a

net weight

UNITS Scrolls between kilograms and pounds

Turns scale on or off and returns scale to zero weight

Indicator Displayed Messages:

L0 Battery is weak

After five minutes scale will turn off

Auto Zero Tracking:

Includes AZT (Auto Zero Tracking) at 0.5 or manual push button to reestablish zero reference when displayed weight is less than 2% of capacity

Overload Capacity: Capable of withstanding

400 lb / 200 kg of weight without damaging the scale

Auto Shutdown: To conserve battery life the display will shutdown after two minutes of non-use. Can be configured via the keypad for Off, two or four minutes.

Operating Temperature: 42° F to 104° F / 5° C to 40° C

Product Dimension (L x W x H):

10.95" x 12.50" x 2.20" / 278 mm x 318 mm x 56 mm

Product Weight: 6 lb / 3 kg

Packaging Dimension (L x W x H):

15.2" x 13.1" x 2.9" / 386 mm x 334 mm x 56 mm

Shipping Weight: 8 lb / 4 kg

Agency Approvals: UKCA, CE, RoHS 3, WEEE, FCC







brecknellscales.com brecknellscales.co.uk

Part of Avery Weigh-Tronix