

## LOAD CELL ELECTRICAL CONNECTION

Listed below are some of many load cell electrical connections.

As you know there are different wire configurations for each manufacturer of the load cell; please confirm with the direct manufacturer to get the correct color code information for your model.

### Avery Weigh-Tronix

Green +Excitation  
 Black -Excitation  
 White +Signal  
 Red -Signal  
 Yellow +Sense  
 Blue -Sense  
 Bare Shield

### Salter Brecknell Pegasus

Red +Excitation  
 Black -Excitation  
 Green +Signal  
 White -Signal  
 Bare Shield

### Electroscale

Red +Excitation  
 Black -Excitation  
 Green +Signal  
 White -Signal  
 Orange +Sense  
 Blue -Sense  
 Shield Bare

### NCI

Red +Excitation  
 Black -Excitation  
 White +Signal  
 Green -Signal  
 Bare Shield

### Toledo

Green +Excitation  
 Black -Excitation  
 White +Signal  
 Red -Signal  
 Yellow Shield

### Cardinal

Green +Excitation  
 Black -Excitation  
 White +Signal  
 Red -Signal  
 Shield Bare

### HBM

Green +Excitation  
 Black -Excitation  
 White +Signal  
 Red -Signal  
 Yellow Shield

### Revere

Green +Excitation  
 Black -Excitation  
 White +Signal  
 Red -Signal  
 Orange Shield

### Rice Lake

Red +Excitation  
 Black -Excitation  
 Green +Signal  
 White -Signal  
 Bare Shield

### Sensortronics

Red +Excitation  
 Black -Excitation  
 Green +Signal  
 White -Signal  
 Bare Shield

### Sensortronics (60007)

Green +Excitation  
 Black -Excitation  
 White +Signal  
 Red -Signal  
 Yellow Shield