

### IP67 Waterproof Portion Control Scale



The 6030 Portion Control scale lessens the amount of food scrapped by accurately weighing the ingredients and portions served. This simple, weight-only electronic kitchen scale is constructed with a food grade stainless steel upper cover and a removable stainless steel platter for easy cleaning making it ideal for use in washdown environments.

The 6030 has two important approvals for scales used in the retail industry. The IP67 rating protects the scale from dust and against the effects of short-term immersion in less than 3.2 ft. / 1m deep for a half an hour and NSF ensures that the product and facility where the product is made meets NSF standards for food safety. These capabilities are not found in many entry level kitchen/catering scales while also offering lasting performance.



#### Accuracy

Within 0.06% of full load



#### Capacity

5000 g x 1 g  
10 lb x 0.002 lb  
10 lb x 0.05 oz  
160 oz x 0.05 oz



#### Power

9 volt alkaline battery (included)



#### Display

0.8"/ 20 mm LCD with five digits



#### Construction

Food grade stainless steel upper cover and removable stainless steel platter for easy cleaning



#### Operator Keys

On/Off, Tare/Zero, Units

# 6030 IP67 Weatherproof Portion Control Scale

## Specifications

**Capacity:** 5000 g x 1 g, 10 lb x 0.002 lb, 10 lb x 0.05 oz,  
160 oz x 0.05 oz

**Display:** LCD

**Keyboard:** On/off, tare/zero, units

**Unit:** lb, lb/oz, oz, kg, g

**Power:** 9V battery

**Battery Life:** 20 hours continuous use

**Operating Temperature:** 41° F - 95° F / 5° C - 35° C

**Platform Dimension (L x W):**

5.9" x 4.7" / 150 mm x 120 mm

**Product Dimension (L x W x H):**

6.6" x 5.9" x 2"

170 mm x 150 mm x 40 mm

**Product Weight:** 1.5 lb / 0.6 kg

**Packaging Dimension (L x W x H):**

10" x 7.75" x 3"

254 mm x 196 mm x 76 mm

**Shipping Weight:** 2 lb / 1 kg

**Certifications:** UKCA, CE, RoHS 3, WEEE, FCC,  
Prop 65



**Brecknell®**

[brecknellscales.com](http://brecknellscales.com)

[brecknellscales.co.uk](http://brecknellscales.co.uk)

Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2022 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

6030\_L\_501451.indd  
V2 AWT35-501451