

# Brecknell

## Model C3235

### Waterproof Check Weigher



The C3235 is a waterproof NSF check weigher for the rapid indication of weight and over, under, accept tolerances in washdown environments.

Available in a choice of 6 lb / 3 kg, 12 lb / 6 kg and 30 lb / 15 kg capacities with resolution of 1 part in 6000 the C3235 is ideal for portion controlling, food processing and catering kitchens applications.

Simple to operate the keyboard has four buttons – off, on/zero, push button tare and function. The function key gives access to the check weigher set up for targets and tolerances (LED and audible alarm), unit switching and count modes.

A battery charge indicator is built in to the display giving an instant check on the condition of the battery.



#### Accuracy

Within 0.05% at full load



#### Capacity

6 lb x 0.001 lb / 3 kg x 0.0005 kg  
12 lb x 0.002 lb / 6 kg x 0.001 kg  
30 lb x 0.005 lb / 15 kg x 0.002 kg



#### Power

Internal main/AC adapter and rechargeable battery (approx. 20 hours)



#### Display

Six digit, 0.5" / 13 mm high seven segment bright red LED display accept, over, under LED



#### Construction

Washable and corrosion free  
ABS/stainless steel housing with  
food safe stainless steel weight platter



#### Operator Keys

Off, Zero, Function, Tare

VALUE IN  
WEIGHING

# Model C3235 Waterproof Check Weigher

## Specifications

### Capacity:

6 lb x 0.001 lb / 3 kg x 0.5 g  
12 lb x 0.002 lb / 6 kg x 1 g  
30 lb x 0.005 lb / 15 kg x 2 g

### Platform Dimension (L x W x H)

9" x 7 1/2" x 0.5"  
229 mm x 190 mm x 13 mm

**Construction:** Rugged ABS plastic lower housing, stainless steel upper housing (IP66) and stainless steel weighing platter

**Display:** Sealed watertight seven segment, six digit, 0.5" / 13 mm high red LED with annunciators

**Annunciators:** kg, g, lb, oz, tare, over, under, accept, count, zero, and battery voltage

**Keyboard:** On/Zero, Off, Tare, Function. The function key gives access to checkweigh targets (with audible alarm), unit switching and count.

**Unit:** lb, lb/oz, kg, g

**Functions:** Count, unit switching, check weigh limits with alarm, auto off after 10 minutes of inactivity

**Power:** Internal main/AC adapter and rechargeable battery (6V - 4.5Ah)

**Battery Life:** Approximately 20 hours (charge time is 12 hours)

### Operating Temperature:

23° F to 95° F / -5° C to 35° C

### Scale Dimension (L x W x H):

9.25" x 11" x 4" / 235 mm x 285 mm x 110 mm

**Weight:** 8 lb / 3.7 kg

### Packaging Dimension (L x W x H):

13.25" x 11" x 5.75"  
337 mm x 280 mm x 146 mm

**Shipping Weight:** 10 lb / 4.5 kg

**Certifications:** NSF, full FCC compliance, Prop 65, CEC, UL approved power adapter



**Brecknell®**

[brecknellscales.com](http://brecknellscales.com)

[brecknellscales.co.uk](http://brecknellscales.co.uk)

Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2022 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

C3235\_L\_500058.indd  
V2 AWT35-500058