

Brecknell

PC3060

Price Computing Scale



EU Approved



The PC3060 Price Computing Scale is NTEP approved at 3,000d Class III. By combining two capacities into one scale, it provides you with a wider weighing range. The 30/60 lb and 15/30 kg capacities allow you to weigh smaller and larger products on the same scale without losing resolution.

The large, easy-to-read back lit dual display shows the weight, unit price and total price and allows the customer to view the information at the same time. It features an auto unit price clear to clear the last unit price once the scale returns to zero, stores up to ten most popular PLU's and it can accumulate up to 100 entries and calculate what change needs to be given back to the customer.

The small footprint takes up little valuable counter space. The food grade 304 stainless steel weight platter protects against corrosion and is easily sanitized, while providing an attractive finish.

The scale operates on an AC power adapter (included) or a 6V/3.2 Ah lead acid rechargeable battery that provides up to 40 hours of battery life. The dual power option gives you portability without having to locate power outlets.



Accuracy

NTEP & EC approved Class III
3000 divisions, 30/60 lb (15/30 kg)
multi-interval



Capacity

30/60 lb x 0.01/0.02 lb
15/30 kg x 0.005/0.01 kg



Power

AC power adapter and rechargeable
batteries (included) with up to 40 hours
of battery life



Display

Three large, easy-to-read operator
and customer facing LCD displays
with blue backlight



Construction

Compact and robust ABS plastic housing
with food grade 304 stainless steel weight
platter



Operator Keys

Eight function keys and 12 numeric
entry keys: Change, Memory Add, PLU,
Save, Quantity, Zero, Units, Tare

VALUE IN
WEIGHING

PC3060 Price Computing Scale

Specifications

Capacity (multi-interval):

30/60 lb x 0.01/0.02 lb
15/30 kg x 0.005/0.01 kg

Accuracy: 3000d NTEP / EC approved to Class III

Unit Price: lb, kg

Key Features: Ten pre-stored PLU's, auto price clear and up to 100 entry accumulator, RS232 port (ECR compatible)

Display: Six large 2.5" x 0.8" / 65 mm x 20 mm high LCD display with blue backlit ½" / 12 mm high digits for displaying weight, unit price and total price

Operator Keys: Eight function keys and 12 numeric entry keys: Change, Memory Add, PLU, Save, Quantity, Zero, Units, Tare

Construction: ABS housing with food grade 304 stainless steel weighing platter

Power: 120V 500mA power adapter (included) and a 6V/3.2 Ah lead acid rechargeable battery

Battery Life: 40 hours

Tare: 100%

Operating Temperature:

14° F to 104° F / -10° C to 40° C

Scale Dimension (L x W x H):

12.3" x 10.3" x 4.3" / 313 mm x 263 mm x 109 mm

Platform Dimension (L x W):

8" x 10.3" / 204 mm x 263 mm

Product Weight: 7.2 lb / 3.3 kg

Packaging Dimension (L x W x H):

14.4" x 13.2" x 7.5" / 365 mm x 335 mm x 190 mm

Shipping Weight: 8 lb / 3.6 kg

Certifications: 3000d NTEP CC #18-119, 3000d EC #0200-NAWI-05154, CE, RoHS



Brecknell®

brecknellscales.com

brecknellscales.co.uk

Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2022 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

PC3060_L_501839.indd
V2 AWT35-501830