Brecknell Model 405-LCD

Portion Control Scale






The 405-LCD General Purpose Scale is ideal for industrial kitchens or food prep areas where portion control of ingredients is essential. Its 100% subtractive tare allows the operator to quickly tare off each ingredient as it is loaded on the scale. The food grade stainless steel platter is removable, making it easy-to-clean. The clear LCD backlit display makes it easy-to-read in both indoor and outdoor conditions.

The base is constructed of ABS plastic, which provides outstanding protection for daily usage and helps to lock out moisture.

The 405-LCD features selectable lb, oz, lb/oz, kg, gram, units and a 100% tare feature. With a resolution of 0.002 lb / 1 g for the 12 lb / 6 kg model and 0.005 lb / 2 g for the 30 lb / 15 kg, the 405-LCD Compact Bench Scale is accurate for any general weighing application.

A wipe-down plastic cover comes standard to protect the display, keyboard and housing from dust and food particles.







9V 600mA power supply (included) or four AA batteries (not included)







Construction

ABS plastic housing with food safe 304 stainless steel weight platter



OOOOO Operator Keys

Tare/Unit, On/Off/Zero

Model 405-LCD Portion Control Scale

Specifications

Capacity:

405-6: 405-15

12 lb x 0.002 lb 30 lb x 0005 lb 192 oz x 0.05 oz 480 oz x 1 oz 12 lb x 0.05 oz 30 lb x 0.1 oz 6 kg x 0.001 kg 15 kg x 0.002 kg 6000 g x 1 g 15000 g x 2 g

Display: Large, easy-to-read, 0.65"/ 16.5 mm high digit LCD backlit display

Keyboard: Intuitive two-button operation Tare/Unit, On/Off/Zero

Unit: lb, oz, lb/oz, kg, g

Power: Comes standard with a switch mode AC adapter with interchange plug ends to cover UK, EU and USA plug requirements (p/n AWT05-100540), or it can be battery power by four AA batteries (not included)

Standard Features: Integrated level bubble, adjustable feet, selectable auto-off and 100% subtractive tare

Battery Life: Energy-efficient design operates for up to 38 hours

Operating Temperature:

41° F - 95° F / 5° C - 35° C

Platform Dimension (L x W): 8.5" x 9.5" / 215 mm x 245 mm

Scale Dimension (L x W x H):

12" x 10" x 4.25" / 305 mm x 255 mm x 110 mm

Packaging Dimension (L x W x H):

15" x 12" x 7" / 385 mm x 305 mm x 180 mm

Shipping Weight: 10 lb / 5 kg

Certifications: FCC compliant, Prop 65, ETL power

adapter, UKCA, CE, RoHS 3, WEEE







brecknellscales.com brecknellscales.co.uk

Part of Avery Weigh-Tronix