

Brecknell

DS1000-LCD

High Precision Floor Scale



Shown with optional indicator stand

DS1000-LCD Drum Weigher Scale is ideal for any busy shipping area where goods are constantly being moved around by pallet trucks or monitoring drum weights.

This low-profile, robust, IP65-rated waterproof platform sits close to the ground and includes a gentle 9% entry/exit ramp, providing a safe, smooth way to roll drums on and off the scale.

It comes standard with an easy-to-use, pre-calibrated indicator featuring a large backlit LCD display for clear visibility in all lighting conditions.



Accuracy

Within 0.1% at full load



Capacity

500 kg x 0.1 kg / 1000 lb x 0.2 lb



Power

9V 600mA universal power supply with USA/UK/EU adapters (included) or six AA batteries (not included)



Display

Six large, easy-to-read 38 mm / 1.5" high digits, large seven segment LCD with white backlight



Construction

Powder coated rugged smooth steel deck structure and built-in ramps, fitted with two handles and wheels to easily relocate. Robust ABS plastic indicator with bench or pole brackets for mounting.



Operator Keys

On/Off/Zero, Tare, Unit, Print, Hold, Accumulate/Total

VALUE IN
WEIGHING

DS1000-LCD Floor Scale

SBI 210 Indicator Specifications

Construction: Robust ABS housing

Annunciators: -0-, motion, gross, net, tare, hold, pcs, %, HI/OK/LOW, battery, accumulation

Units: kg, lb, pcs, %

Tare: 100% subtractive. Ideal when filling to a set recipe.

Check Weighing: Used when packing or filling to a set weight. This provides the operator a fast & simple visual to let them know the product is within the accepted weight window.

Counting: Used for stock control or to quickly work out the quantity of items within a box

Accumulation: Used when packing multiple items into one consignment to get the final consignment weight total

Hold: Allows a stable weight to be easily held once the goods have been removed from the scale

Percentage: Allows the operator to easily carry out weightments on % basis

Indicator Mounting: Can be desk mounted or pole mounted either vertically or horizontally

Display: Large, easy-to-read six digit 38 mm / 1.5" high digit LCD with backlight

Power: 9V 600mA, 110-230V switch mode external power supply with USA/UK/EU interchangeable plug adapters or six AA batteries (not included)

Built-in Power Saving Features: Subject to how the scale is to be used, there are a number of ways to prolong the battery life of this scale. From turning off the backlight to setting the auto-off to engage when the scale is not in use.

Communication: One USB (VCP) and one RS232 bi-directional full duplex port. Optional COM cables.

Print Format: Configurable


Calibration: Front panel calibration

Indicator Packing: Comes packed within the base packing box

Operating Temperature:
-10° C to 40° C / 14° F to 104° F

DS1000-LCD Floor Specifications

Product Dimension:



Ramp: Designed with built-in 9 degree gradual angle to make entry and exit safe and easy

Product Weight: 47 kg / 103.4 lb

Packaging Dimension (L x W x H):
1210 mm x 1200 mm x 205 mm
47.6" x 47.2" x 8.0"

Shipping Weight: 48.5 kg / 106.7 lb

Packaging Contents: DS1000-LCD platform, indicator, power supply with UK/EU/USA plugs and indicator desk and pole mounting brackets

Certifications: FCC compliant, Prop 65, UL/CUL power adapter, UKCA, CE, RoHS 3, WEEE

Options: Indicator floor stand, guard rail kit

Construction: Heavy duty welded channel support with powder coat paint for corrosion protection, adjustable locking feet, two handles and wheels

Load Cells: Four waterproof shear beam load cells connect to the IP65 junction box with 3 m / 10 ft interface cable

STAY
CONNECTED
WITH US!



@brecknell-scales



@brecknell_scales

Brecknell
www.brecknellscales.com

Part of Avery Weigh-Tronix