

Brecknell

PS3000-LCD

Floor Scale



Shown with optional indicator stand

The PS1000 and PS2000 Portable Floor Scales have a rugged tread plate steel platform, ideal for weighing larger animals, pets, and goods. No installation or maintenance is required - simply place on a hard, level surface and adjust the footpads. Ramped ends provide easy access for livestock and equipment like jacks or trolleys.

They feature a rust-proof stainless-steel top, low-profile base, and an ABS/steel-housed indicator. Each scale includes a standard RS-232 port for printing data or interfacing with UPS/NCI shipping software.

The convenient Hold Weight mode freezes the last weight shown on the screen, allowing hands-free operation.

Dual power options - battery and AC adapter - support both portable use and permanent installation on a wall or desk.



Accuracy

Within 0.1%



Capacity

1500 kg x 0.5 kg / 3000 lb x 1.0 lb



Power

9V 600mA universal power supply with USA/UK/EU adapters (included) or six AA batteries (not included)



Display

Six large, easy-to-read 38 mm / 1.5" high digits with large seven segment LCD with white backlight



Construction

Mild steel construction, heavy duty welded channel and powder coated surface finish. Robust ABS plastic indicator with bench or pole brackets for mounting.



Operator Keys

On/Off/Zero, Tare, Unit, Print, Hold, Accumulate/Total

VALUE IN
WEIGHING

PS3000-LCD Floor Scale

SBI 210 Indicator Specifications

Construction: Robust ABS housing

Annunciators: -0-, motion, gross, net, tare, hold, pcs, %, HI/OK/LOW, battery, accumulation

Units: kg, lb, pcs, %

Tare: 100% subtractive

Check Weighing: Used when packing or filling to a set weight. This provides the operator a fast & simple visual to let them know the product is within the accepted weight window.

Counting: Used for stock control or to quickly work out the quantity of items within a box

Accumulation: Used when packing multiple items into one consignment to get the final consignment weight total

Hold: Allows a stable weight to be easily held once the goods have been removed from the scale

Animal Averaging Hold: Allows the animal weight to be correctly calculated even when it slightly moves around. Allows the animal to be weighed by a single person. This easy-to-use hold feature allows the scale to capture the weight and retain it while you tend to the animal.

Percentage: Allows the operator to easily carry out weightments on % basis

Mounting Brackets: Can be desk mounted or pole mounted either vertical or horizontally

Display: Large, easy-to-read six digit 38 mm / 1.5" high digit LCD with backlight

Power: 9V 600mA, 110-230V switch mode external power supply with USA/UK/EU interchangeable plug adapters or six AA batteries (not included)

Connection: 250 mm / 9.8" cable is fixed to indicator side with quick release connector. An additional 3 m / 10' of cable is connected to the floor scale junction box.

Built-in Power Saving Features: Subject to how the scale is to be used, there are a number of ways to prolong the battery life of this scale. From turning off the backlight to setting the auto off to engage when the scale is not in use.

Communication: One USB (VCP) and one RS-232 bi-directional full duplex port. Optional COM cables.

Calibration: Front panel calibration

Indicator Packing: Comes packed in a separate box along with the floor scale base

Operating Temperature:
-10° C to 40° C / 14° F to 104° F

PS3000-LCD Scale Specifications

Capacity: 1500 kg x 0.5 kg / 3000 lb x 1.0 lb

Construction: Powder coat paint for corrosion protection. 4 mm thick mild steel construction with safety tread plate surface and rubber mat.

Load Cells: Four OIML C3 waterproof IP67 350 Ohm shear beam load cells

J-Box: Weatherproof IP65 ABS junction box with floor scale top access for ease of installation and service

Anti-slip Rubber Mat: Easy on animal hooves, reduces noise and risk of slipping (included)

150% Overload Protection

Platform Dimension (L x W x H):
2000 mm x 1000 mm x 100 mm
78.75" x 39.37" x 3.93"

Platform Weight: 120 kg / 264 lb

Packaging Dimension (L x W x H):
2050 mm x 1050 mm x 180 mm / 81" x 42" x 7.1"

Shipping Weight (platform + indicator):
125 + 2 kg / 275 + 4.4 lb

Certifications: FCC compliant, Prop 65, UL/CUL power adapter, UKCA, CE, RoHS 3, WEEE

Options: Indicator floor stand, platform foot, RS-232, USB cables

STAY
CONNECTED
WITH US!



@brecknell-scales



@brecknell_scales

Brecknell
www.brecknellscales.com

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2025 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

Part of Avery Weigh-Tronix

PS3000_LCD_L_RoW_100080.indd
V4 AWT35-100068