

# SuperSamson

## Tubular Balance - Spring Type



The Brecknell Salter SuperSamson is an affordable Spring balances that is ideal for a wide range of weighing applications from Aid agency use to fishing, health & safety to education usages.

Designed to be light weight, portable and very easy-to-use. Once a weight is applied to the one end of the SuperSamson balance the inner tube quickly extends to reveals the correct weigh of the object being weighed.



### Accuracy

Within  $\pm 0.5\%$  at full capacity



### Capacity

5 kg x 25 g  
25 kg x 100 g



### Portability

Small, compact design



### Readability

1:125 division on a white background with clear black weight markings



### Construction

Compact resistant ABS housing with steel top and bottom hooks (100% overload protection)



### Easy-to-Use

Simple functionality with easy adjust tare wheel

# SuperSamson Tubular Balance - Spring Type

---

## Specifications

---

**Balance Type:** Handheld mechanical

**Capacity:** 5 kg x 25 g, 25 kg x 100 g

**Unit:** kg/g

**Readability:** 1:125 division on a white background with clear black weight markings. Reading time under three seconds.

**Construction:** Durable robust, tubular housing made from tough ABS plastic. Fully corrosion protected top hook and bottom hook. 100% overload protection with easy to adjust tare mechanism.

**Scale Dimension (L x W):**

**With Hooks:** 300 mm x 26 mm

**Without Hooks:** 210 mm x 26 mm

**Product Weight:** 135 g

**Packaging Dimension (L x W x H):**

290 mm x 38 mm x 28 mm

**Shipping Weight:** 155 g

**Packaging Type:** Retail, printed carton



 **Brecknell**

[www.brecknellscales.com](http://www.brecknellscales.com)

[www.brecknellscales.co.uk](http://www.brecknellscales.co.uk)

*Part of Avery Weigh-Tronix*

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works:"). Copyright © 2022 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

SuperSamson\_RoW\_L\_100097.indd  
V1 AWT35-100097