

Brecknell

Model C3236

Washdown Check Weigher



The C3236 is a fully washdown, stainless steel scale ideal for most general purpose weighing, check weighing or portion control applications. Designed for speed and efficiency with limited operator training required, the C3236 is ideal for applications where food preparation or portion control accuracy is essential.

General Weighing Mode: The clear, easy-to-read display allows operators to quickly and easily view weight data before pressing tare between ingredients.

Check Weighing Mode: Ideal for repetitive weighing applications. It can easily be set so the operator can quickly tell if the weight is within a known tolerance with the low, accept, high annunciators and audio alarm.



Accuracy

0.04% at full load



Capacity

3 kg x 0.2 g / 6 lb x 0.01 oz
7 kg x 0.5 g / 15 lb x 0.02 oz
15 kg x 1 g / 30 lb x 0.05 oz



Power

Removable AC power adapter (included) along with a built-in rechargeable lead acid battery



Display

Fast and easy-to-read 15 mm / 0.6" high red LED display with easy-to-see low, ok and high annunciators



Construction

With a food grade 304 stainless steel housing and top pan and IP68 (NEMA4X) water ingress protection, this scale is easy-to-clean and ideal for use in most washdown environments.



Operating Keys

On/Zero/Tare, Function, Unit, Off

VALUE IN WEIGHING

C3236 Washdown Check Weigher

Specifications

Capacity:

3 kg x 0.0002 kg / 6 lb x 0.0005 lb

7 kg x 0.0005 kg / 15 lb x 0.001 lb

15 kg x 0.001 kg / 30 lb x 0.002 lb

Accuracy: 0.04% at full load

Unit: kg, g, lb, lb-oz (not legal-for-trade)

Main Functionality: General weighing and check weighing with audio low, ok and high buzzer

Display: Large 30 mm x 90 mm / 1.2" x 3.5" red LED display with five 0.6" / 15 mm high digits

Operator Keys: On/Zero/Tare, Function, Unit, Off

Power: Removable AC power adapter (included) along with a built-in rechargeable lead acid battery

Battery Life: Up to 62 hours

Tare: 100%

Operating Temperature:

-10° C to 40° C / 14° F to 104° F

Scale Dimension (L x W x H):

330 mm x 290 mm x 110 mm / 13" x 11.4" x 4.3"

Platform Dimension (L x W):

190 mm x 255 mm / 7.5" x 10"

Product Weight: 4.8 kg / 10.5 lb

Packaging Dimension (L x W x H):

365 mm x 335 mm x 145 mm / 14.4" x 13.2" x 5.7"

Shipping Weight: 3.5 kg / 7.7 lb

Certifications: FCC, Prop 65, UL, UKCA, CE, RoHS 3, WEEE directive



Brecknell

www.brecknellscales.com

www.brecknellscales.co.uk

Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2023 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

C3236_RoW_L_100120.indd
V5 AWT35-100120