



ONE SCALE. TWO CAPACITIES. SMART PRECISION.

By automatically adjusting resolution across two capacity ranges, the C3236 Portion Control/Check weighing Scale ensures accurate weighing whether the load is small or large - eliminating the need for multiple scales.

The C3236 is a portable, washdown stainless steel bench scale ideal for general weighing, checkweighing, and portion control applications where speed, efficiency, and minimal operator input are required.

General Weighing Mode: The clear, easy-to-read display allows operators to quickly view weight data and easily tare between ingredients.

Check Weighing Mode: Ideal for repetitive weighing applications. Operators can instantly see whether the weight is within the target tolerance using the low, accept, and high annunciators, supported by an audible alarm.



Accuracy

Within 0.04% at full load



Dual Range Capacity

6-15 lb x 0.01-0.02 oz
 15-30 lb x 0.02-0.05 oz
 3-7 kg x 0.0002-0.0005 kg
 7-15 kg x 0.0005-0.001 kg



Power

Waterproof AC power adapter (included) or built-in rechargeable lead acid battery



Display

Fast and easy-to-read 15 mm / 0.6" high red LED display with easy-to-see low, ok and high annunciators



Construction

Designed for washdown environments, with a food-grade 304 stainless steel housing and top pan.



Operating Keys

On/Zero/Tare, Unit.
 Function: Check weighing

C3236 Washdown Check Weigher

Specifications

Capacity:

C3236-7
3-7 kg x 0.0002-0.0005 kg
3000-7000 g x 0.2-0.5 g
6-15 lb x 0.0005-0.001 lb
6-15 lb x 0.01-0.02 oz

C3236-15
7-15 kg x 0.0005-0.001 kg
7000-15000 g x 0.5-1 g
6-15 lb x 0.001-0.002 lb
15-30 lb x 0.02-0.05 oz

Unit: kg, g, lb, lb-oz

Main Functionality: General weighing and check weighing with audio low, ok and high buzzer

Display: Large 30 mm x 90 mm / 1.2" x 3.5" red LED display with five 0.6" / 15 mm high digits

Operator Keys: On/Zero/Tare, Unit
Function: Check weighing

Power: Removable AC power adapter (included) along with a built-in rechargeable lead acid battery

Battery Life: Up to 62 hours

Tare: 100%

Operating Temperature:
-10° C to 40° C / 14° F to 104° F

Scale Dimension (L x W x H):
330 mm x 290 mm x 110 mm 13" x 11.4" x 4.3"

Platform Dimension (L x W):
190 mm x 255 mm / 7.5" x 10"

Product Weight: 4.8 kg / 10.5 lb

Packaging Dimension (L x W x H):
365 mm x 335 mm x 145 mm / 14.4" x 13.2" x 5.7"

Shipping Weight: 5 kg / 10 lb

Certifications: FCC compliant, Prop 65, UL/CUL power adapter, UKCA, CE, RoHS 3, WEEE



STAY
CONNECTED
WITH US!



@brecknell-scales



@brecknell_scales

Brecknell
www.brecknellscales.com

Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2026 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

C3236_RoW_L_100120.indd
V6 AWT35-100120