# **Brecknell** WS15/WS60/WS120

Light Capacity Platform Scales



WS15, WS60 and WS120 bench scales offer the user a competitively priced bench scale with 1:3000 resolution - giving 15 kg x 5g, 60 kg x 20 g or 120 kg x 50 g performance, incorporating four full load bridge load cells, with self-levelling feet.

The tough low profi le platform has a brushed stainless steel top for ease of cleaning and a generous platform size. It is mounted on four anti-slip rubber feet.

Three metres of cable connects the platform to the brushed stainless steel display pod which features clear 17 mm high LCD digits. A plastic display pod bracket is included

to allow the display to be wall or bench mounted.

Key display features are on/off; push button tare to enable weights of empty containers to be removed and net weight only displayed; kg / lb switching to give readings in either metric or imperial measures and hold which allows the weight to be frozen, even when the package is removed.

To extend battery life an auto-off feature is standard, with the scale switching itself off after 2 minutes of inactivity.



ccuracy Within 0.15% of full capacity

Four AAA batteries (not included)

or 9 VDC, 600mA adapter

#### Capacity

WS15: 15 kg x 5 g / 30 lb x 0.01 lb WS60: 60 kg x 20 g / 130 lb x 0.05 lb WS120: 120 kg x 50 g / 260 lb x 0.1 lb



#### Display

Five 17 / 0.625" mm digits

LCD with backlight



VALUE IN

WEIGHING

#### Construction

**Power** 

Low profile stainless steel platform with mild steel understructure, stainless steel/ABS indicator will wall bracket and desk mount included



**Operating Keys** On/Off/Zero, Tare, Units, Hold

## WS15/WS60/WS120 Portable Bench Scale

### **Specifications**

#### Capacity:

WS15: 15 kg x 5 g / 30 lb x 0.01 lb WS60: 60 kg x 20 g / 130 lb x 0.05 lb WS120: 120 kg x 50 g / 260 lb x 0.1 lb

**Overload Capacity:** Capable of withstanding 150% capacity of weight without damaging scale

**Power:** Four AAA batteries (not included) or 9 VDC, 600mA adapter

Platform Dimension (L x W x H): 380 mm x 300 mm x 27 mm

Display Pod Dimension (L x W x H): 158 mm x 80 mm x 27 mm **Display:** Five digit 17 mm / 0.625" high with seven segment LCD

Function Keys: On/off; tare; kg/lb; hold

Annunciators: Zero; net; hold; kg/lb

Tare: 100% subtractive

Operating Temperature: +5° C to +40° C

Product Weight: 3.9 kg

Packaging Dimension (L x W x H): 450 mm x 400 mm x 60 mm

Shipping Weight: 5 kg

Certifications: FCC compliant, Prop 65, UL/CUL power adapter, UKCA, CE, RoHS 3, WEEE





WS15 for use in portion control applications



Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works:). Copyright © 2024 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

WS15WS60WS120\_RoW\_L\_1000140.indd V4 AWT35-100140