



Brecknell

Model C3236

Washdown Check Weigher



ONE SCALE. TWO CAPACITIES. SMART PRECISION.

By automatically adjusting resolution across two capacity ranges, the C3236 Portion Control/Check weighing Scale ensures accurate weighing whether the load is small or large - eliminating the need for multiple scales.

The C3236 is a portable, washdown stainless steel bench scale ideal for general weighing, checkweighing, and portion control applications where speed, efficiency, and minimal operator input are required.

General Weighing Mode: The clear, easy-to-read display allows operators to quickly view weight data and easily tare between ingredients.

Check Weighing Mode: Ideal for repetitive weighing applications. Operators can instantly see whether the weight is within the target tolerance using the low, accept, and high annunciators, supported by an audible alarm.



Accuracy

Within 0.04% at full load



Power

Waterproof AC power adapter (included)
or built-in rechargeable lead acid battery



Construction

Designed for washdown environments,
with a food-grade 304 stainless steel
housing and top pan.



Dual Range Capacity

6-15 lb x 0.01-0.02 oz
15-30 lb x 0.02-0.05 oz
3-7 kg x 0.0002-0.0005 kg
7-15 kg x 0.0005-0.001 kg



Display

Fast and easy-to-read 0.6" / 15 mm high
red LED display with easy-to-see low, ok
and high annunciators



Operator Keys

On/Zero/Tare, Unit
Function: Check weighing

VALUE IN
WEIGHING

C3236 Washdown Check Weigher

Specifications

Capacity:

C3236-7

3-7 kg x 0.0002-0.0005 kg

3000-7000 g x 0.2-0.5 g

6-15 lb x 0.0005-0.001 lb

6-15 lb x 0.01-0.02 oz

C3236-15

7-15 kg x 0.0005-0.001 kg

7000-15000 g x 0.5-1 g

6-15 lb x 0.001-0.002 lb

15-30 lb x 0.02-0.05 oz

Unit: lb, kg, g, lb-oz

Main Functionality: General weighing and check weighing with audio low, ok and high buzzer

Display: Large 1.2" x 3.5" / 30 mm x 90 mm red LED display with five 0.6" / 15 mm high digits

Operator Keys: On/Zero/Tare, Unit
Function: Check weighing

Power: Removable AC power adapter (included) along with a built-in rechargeable lead acid battery

Battery Life: Up to 62 hours

Tare: 100%

Operating Temperature:

14° F to 104° F / -10° C to 40° C

Scale Dimension (L x W x H):

13" x 11.4" x 4.3" / 330 mm x 290 mm x 110 mm

Platform Dimension (L x W):

7.5" x 10" / 190 mm x 255 mm

Product Weight: 10.5 lb / 4.8 kg

Packaging Dimension (L x W x H):

14.4" x 13.2" x 5.7" / 365 mm x 335 mm x 145 mm

Shipping Weight: 10 lb / 5 kg

Certifications: FCC compliant, Prop 65, UL/CUL power adapter, UKCA, CE, RoHS 3, WEEE



STAY
CONNECTED
WITH US!



@brecknell-scales



@brecknell_scales

Brecknell®

brecknellscales.com

Part of Avery Weigh-Tronix

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2026 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

C3236_L_501850.indd
V6 AWT35-501850