

Brecknell**Model 405-LCD**

Portion Control Scale


DR
 DUAL RANGE
 TECHNOLOGY
**ONE SCALE. TWO CAPACITIES. SMART PRECISION.**

By automatically adjusting resolution across two capacity ranges, the 405-LCD Portion Control Scale ensures accurate weighing whether the load is small or large - eliminating the need for multiple scales.

The 405-LCD is ideal for quick weighing tasks in food prep areas, portion control stations, and science classrooms. It features an intuitive two-key operation built into a durable, wipe-down ABS housing, along with a removable 304 food-grade stainless-steel platter for easy cleaning (NSF certified).

It runs on four AA batteries or an AC adapter - offering convenient portability. The large, blue backlit LCD provides a clear, easy-to-read display in any setting.

A wipe-down plastic cover comes standard to protect the display, keyboard and housing from dust and food particles.

**Accuracy**

Within 0.04% at full load

**Dual Range Capacity**

6-15 lb x 0.001-0.002 lb

15-30 lb x 0.002-0.005 lb

3-6 kg x 0.0005-0.001 kg

6-15 kg x 0.001-0.002 kg

**Power**

9V 600mA power supply (included)
or four AA batteries (not included)

**Display**

0.65" / 16.5 mm high digit LCD backlit

**Construction**

ABS plastic housing with food safe
304 stainless steel weight platter

**Operator Keys**

Tare/Unit, On/Off/Zero

**VALUE IN
WEIGHING**

Model 405-LCD Portion Control Scale

Specifications

Capacity:

405-6:	405-15
3-6 kg x 0.0005-0.001 kg	6-15 kg x 0.001-0.002 kg
3000-6000 g x 0.5-1 g	6000-15000 g x 1-2 g
6-15 lb x 0.001-0.002 lb	15-30 lb x 0.002-0.005 lb
94-192 oz x 0.02-0.05 oz	240-480 oz x 0.05-0.1 oz

Display: Large, easy-to-read, 0.65" / 16.5 mm high digit LCD backlit display

Keyboard: Intuitive two-button operation Tare/Unit, On/Off/Zero

Unit: lb, oz, lb/oz, kg, g

Power: Comes standard with a switch mode AC adapter with interchange plug ends to cover UK, EU and USA plug requirements (p/n AWT05-100540), or it can be battery power by four AA batteries (not included)

Standard Features: Integrated level bubble, adjustable feet, selectable auto-off and 100% subtractive tare

Battery Life: Energy-efficient design operates for up to 38 hours

Operating Temperature:
41° F - 95° F / 5° C - 35° C

Platform Dimension (L x W):
8.5" x 9.5" / 215 mm x 245 mm

Scale Dimension (L x W x H):
12" x 10" x 4.25" / 305 mm x 255 mm x 110 mm

Packaging Dimension (L x W x H):
15" x 12" x 7" / 385 mm x 305 mm x 180 mm

Shipping Weight: 10 lb / 5 kg

Certifications: FCC compliant, Prop 65, ETL power adapter, UKCA, CE, RoHS 3, WEEE



STAY
CONNECTED
WITH US!



Brecknell®
brecknellscales.com