

# Brecknell

## PC3060

### Price Computing Scale



EU Approved



The PC3060 Price Computing Scale is NTEP approved at 3,000d Class III. By combining two capacities into one scale, it provides you with a wider weighing range. The 30/60 lb and 15/30 kg capacities allow you to weigh smaller and larger products on the same scale without losing resolution.

The large, easy-to-read back lit dual display shows the weight, unit price and total price and allows the customer to view the information at the same time. It features an auto unit price clear to clear the last unit price once the scale returns to zero, stores up to ten most popular PLU's and it can accumulate up to 100 entries and calculate what change needs to be given back to the customer.

The small footprint takes up little valuable counter space. The food grade 304 stainless steel weight platter protects against corrosion and is easily sanitized, while providing an attractive finish.

The scale operates on an AC power adapter (included) or a 6V/3.2 Ah lead acid rechargeable battery that provides up to 40 hours of battery life. The dual power option gives you portability without having to locate power outlets.



#### Accuracy

NTEP & EC approved Class III  
3000 divisions, 30/60 lb (15/30 kg)  
multi-interval



#### Capacity

30/60 lb x 0.01/0.02 lb  
15/30 kg x 0.005/0.01 kg



#### Power

AC power adapter and rechargeable  
batteries (included) with up to 40 hours  
of battery life



#### Display

Three large, easy-to-read operator  
and customer facing LCD displays  
with blue backlight



#### Construction

Compact and robust ABS plastic housing  
with food grade 304 stainless steel weight  
platter



#### Operator Keys

Eight function keys and 12 numeric  
entry keys: Change, Memory Add, PLU,  
Save, Quantity, Zero, Units, Tare

VALUE IN  
WEIGHING

# PC3060 Price Computing Scale

## Specifications

**Capacity (multi-interval):**

30/60 lb x 0.01/0.02 lb

15/30 kg x 0.005/0.01 kg

**Accuracy:** 3000d NTEP / EC approved to Class III**Unit Price:** lb, kg**Key Features:** Ten pre-stored PLU's, auto price clear and up to 100 entry accumulator, RS232 port (ECR compatible)**Display:** Six large 2.5" x 0.8" / 65 mm x 20 mm high LCD display with blue backlit ½" / 12 mm high digits for displaying weight, unit price and total price**Operator Keys:** Eight function keys and 12 numeric entry keys: Change, Memory Add, PLU, Save, Quantity, Zero, Units, Tare**Construction:** ABS housing with food grade 304 stainless steel weighing platter**Power:** 120V 500mA power adapter (included) and a 6V/3.2 Ah lead acid rechargeable battery**Battery Life:** 40 hours**Tare:** 100%**Operating Temperature:**

14° F to 104° F / -10° C to 40° C

**Scale Dimension (L x W x H):**

12.3" x 10.3" x 4.3" / 313 mm x 263 mm x 109 mm

**Platform Dimension (L x W):**

8" x 10.3" / 204 mm x 263 mm

**Product Weight:** 7.2 lb / 3.3 kg**Packaging Dimension (L x W x H):**

14.4" x 13.2" x 7.5" / 365 mm x 335 mm x 190 mm

**Shipping Weight:** 8 lb / 3.6 kg**Certifications:** NTEP CC #18-119, 3000d EC #0200-NAWI-05154**Brecknell®**

brecknellscales.com

brecknellscales.co.uk