

# PS165/PS330 Series

## Parcel and Shipping Scale



- **Functionality**– General weighing in lb, lb/oz, kg and basic counting
- **Capacity**– 165 lb x 0.1 lb / 75 kg x 0.05 kg or 330 lb x 0.2 lb / 150 kg x 0.1 kg
- **Construction**– Hard-wearing stainless steel weight platform with four self-leveling feet attached to a compact ABS plastic indicator with metal wall/bench mounting bracket
- **Display**– Large 7" x 3.5" / 180 mm x 90 mm easy-to-read blue back lit LCD display with 1" / 25 mm high digits
- **Power**– AC adapter (included) or four AA batteries (not included)
- **Platform Dimension (L x W x H)**– 15.3" x 12.3" x 1.57" / 390 mm x 310 mm x 40 mm

# PS165/PS330 Series Parcel and Shipping Scales

## Features

The PS165/PS330 Parcel and Shipping Scale offers exceptional value for your money while making fast, easy work out of weighing parcels or boxes. Ideal for use in general weighing, warehouse shipping/receiving areas, and mailrooms.

This dual-powered platform operates from an AC adapter (included) or four AA batteries (not included) that provides up to 36 hours of battery life. Ideal for portable applications without the need to find power outlets.

The PS Parcel and Shipping Scale weighs in lb, lb/oz or kg and has a built-in basic counting feature for counting an assortment of average-sized parts, making it ideal for checking box quantities in shipping or receiving areas.

This parcel and shipping scale comes standard with a hard-wearing stainless steel weighing surface and four self-leveling feet, allowing it to be placed on uneven surfaces. The low profile design of only 1.5" high makes this 15.3" L x 12.3" W platform ideal for being used on work benches without needing to lower the bench height and can easily be stored away when not in use.

Connected to a robust ABS indicator with a large easy-to-read blue back lit display makes the PS Series ideal for environments where lighting is dim. The indicator comes with a wall or desk mounted bracket and a coiled cable allowing the indicator to easily be moved away from the base up to 19.6".



a division of Avery Weigh-Tronix, LLC

### Brecknell

1000 Armstrong Dr., Fairmont, MN 56031  
Toll free: 800-637-0529, Tel: 507-238-8702  
Fax: 507-238-8271  
e-mail: sales@brecknell scales.com  
www.brecknell scales.com



### Brecknell

Foundry Lane, Smethwick  
West Midlands B66 2LP UK  
Tel: +44 (0) 845 246 6717  
Fax: +44 (0) 845 246 6718  
Email: sales@brecknell scales.co.uk  
www.brecknell scales.co.uk



## Specifications

### Capacity:

PS165: 165 lb x 0.1 lb / 75 kg x 0.05 kg

PS330: 330 lb x 0.2 lb / 150 kg x 0.1 kg

**Accuracy:** 0.25% at full capacity

**Unit:** lb, lb/oz, kg

**Main Functionality:** General weighing or basic counting with auto-off after five minutes

**Display:** Five 1" / 25 mm high digit seven segment LCD display with blue backlight

**Operator Keys:** On/Zero/Off, Unit, Count, Tare

**Power:** AC adapter (included) or four AA batteries (not included)

**Battery Life:** 36 hours

**Tare:** 100%

**Auto Zero Tracking:** Two divisions

**Minimum Recommended Piece Weight:** 0.004 lb (2 g) based off a count of 100 pieces

### Operating Temperature:

41° F to 95° F / 5° C to 35° C

### Platform Dimension (L x W):

15.3" x 12.3" x 1.57" / 390 mm x 310 mm x 40 mm

### Indicator Dimension (with bracket) (L x W x H):

8" x 1.2" x 3.7" / 205 mm x 30 mm x 95 mm

**Product Weight:** 7.3 lb / 3.3 kg

### Packaging Dimension (L x W x H):

20" x 18" x 4" / 508 mm x 457 mm x 102 mm

**Shipping Weight:** 11 lb / 4.9 kg

